

HV 8000 - MECHANICAL BOOSTER PUMP

edwardsvacuum.com

HV8000 feature a rugged design for robust and reliable operation in very large scale processes both in the industrial and chemical markets.



Performance

Stable process for consistent output - Suitable for continuous operation over wide pressure ranges.



Adaptability

Easy integration and safe - Optional water cooled exhaust gas after cooler, shaft seal safety purge, temperature monitoring and VFD available.



Reliability

No unplanned downtime - High performance water cooled mechanical shaft seal, large diameter shaft and large helical gears.



Flexibility

Configured to your needs - Can be supplied with standard motor or without motor to allow a local motor to be fitted. Horizontal or vertical flow to suit application and system design.

Technical Data

	Units	HV8000
Displacement 50 Hz	m ³ h ⁻¹ /CFM	7200/4241
Displacement 60 Hz	m ³ h ⁻¹ /CFM	8640/5089
Inlet/outlet connection		10" class 150 ASME B16.5
Inlet/outlet cooling water connection		Rp 1/2 ISO 7-1 (1/2 BSP)
End cover purge gas inlet		Rp 3/8 ISO 7-1 (3/8 BSP)
Pressure differential across pump 50 Hz	mbar/torr	190/143
Pressure differential across pump 60 Hz	mbar/torr	120/90
Max cooling water supply pressure	bar/psi	4.0/58
Max cooling water supply temp	°C/F	35/95
Cooling water flow rate	lmin ⁻¹ /US gal min ⁻¹	15/3.96
Noise level	dB(A)	82
Weight (without motor)	kg/lb	580/1279
Weight (with standard motor) kg	kg/lb	720/1587
Motor Power 50Hz	kW/hp	15/20
Motor Power 60Hz	kW/hp	18.5/25
Oil capacity (vertical gas flow)	litre/gal	8.3/2.18
Dimensions Horizontal flow L x W x H	mm	1737 x 530 x 820
Dimensions Vertical flow L x W x H	mm	1737 x 670 x 638

Ordering information

Product Description	Part Number
HV8000 VF 400 V 50 Hz 230/460 V 60 Hz 18.5 kW BOOSTER	A311-03-940
HV8000 VF 200 V 50 Hz 200/380 V 60 Hz 18.5 kW BOOSTER	A311-03-934
HV8000 VF BARESHAFT BOOSTER	A311-01-985
HV8000 HF 380/400 V 50 Hz 230/460 V 60 Hz 18.5 kW BOOSTER	A311-04-940
HV8000 HF 200 V 50 Hz 200/380 V 60 Hz 18.5 kW BOOSTER	A311-04-934
HV8000 HF BARESHAFT BOOSTER	A311-02-985

ATEX variants available on request

Applications

- Steel degassing
- Metallurgy
- Coating
- Process industry

GLOBAL CONTACTS

Publication Number: 3602 202 9 01
© Edwards Limited 2019. All rights reserved.
Edwards and the Edwards logo are trademarks of Edwards Limited.

Whilst we make every effort to ensure that we accurately describe our products and services, we give no guarantee as to the accuracy or completeness of any information provided in this datasheet.

Edwards Ltd., registered in England and Wales
No. 6124750, registered office: Manor Royal,
Crawley, West Sussex RH10 9LW, United Kingdom.

EMEA

UK	+44 (0) 1444 253 000 (local rate) 0845 921 2223
Belgium	+32 2 300 0730
France	+33 1 4121 1256
Germany	0800 000 1456
Italy	+39 02 48 4471
Israel	+972 8 681 0633

ASIA PACIFIC

China	+86 400 111 9618
India	+91 20 4075 2222
Japan	+81 47 458 8836
Korea	+82 31 716 7070
Singapore	+65 6546 8408
Taiwan	+886 3758 1000

AMERICAS

USA	+1 800 848 9800
Brazil	+55 11 3952 5000

